

Standard Operating Procedures for Flashing BIOS

NOTE: Most BIOS files obtained from our Website that are zipped contain four files that are as follows:

BIOS file
AWDFLASH utility
Autoexec.bat
Readme.txt

Step1: Copy the BIOS file, awdf flash utility file and the autoexec.bat file to a bootable floppy disk. Insert the disk in the floppy drive and reboot the system

Step2: The utility program will run and will copy new BIOS file to your system BIOS.

Step 3: After the BIOS flash completed, you will see a flashing message to hit F1 to reboot the system (Press F1 function key).

Step 4: During the rebooting (noted in step 3) hit the DEL key to enter CMOS. Select (highlight) Load Optimal Settings and then proceed to hit the enter key.

Step 5: Select (highlight) Save and Exit and hit Enter key. System will reboot with new settings.

Note: If no autoexec.bat is present, copy all files to a bootable disk and manually type the command to flash the BIOS at the "A" prompt. The command line should resemble the following: (x's below are considered wildcard characters and will change depending on the true BIOS filename) Continue to Step 2.

```
A:\awdf flash xxxxxxxx.xxx /py /sn /f /cc
```